

KRR-5FH Constants List

Supported library: RCB4Lib_for_Python_V100B

Constants	Value		Button Name
	HEX	DEC	
class KRR_BUTTON(Enum):			
KRR_BUTTON.NONE	0x0000	0	There's no button pressed.
KRR_BUTTON.UP	0x0001	1	Left Group-UP
KRR_BUTTON.DOWN	0x0002	2	Left Group-DOWN
KRR_BUTTON.RIGHT	0x0004	4	Left Group-Right
KRR_BUTTON.LEFT	0x0008	8	Left Group-Left
KRR_BUTTON.TRIANGLE	0x0010	16	Right Group-UP
KRR_BUTTON.CROSS	0x0020	32	Right Group-Down
KRR_BUTTON.CIRCLE	0x0040	64	Right Group-Right
KRR_BUTTON.SQUARE	0x0100	256	Right Group-Left
KRR_BUTTON.S1	0x0200	512	Shift Button-1
KRR_BUTTON.S2	0x0400	1024	Shift Button-2
KRR_BUTTON.S3	0x0800	2048	Shift Button-3
KRR_BUTTON.S4	0x1000	4096	Shift Button-4
KRR_BUTTON.FALSE	0xFFFF		Error detection

You can specify a combination of buttons.

ex. buttonData = Rcb4BaseLib.KRR_BUTTON.UP.value | Rcb4BaseLib.KRR_BUTTON.S1.value

KONDO KAGAKU CO.,LTD.

KRC-5FH Button Name

